



1085 Budapest, József krt. 66.

+36 30 9 478 913 | pmsaudio@t-email.hu | www.pmsaudio.com

	Megnevezés	Listaár
E 670	SPECIAL EDITION HEAD	886922
E 670 EL34	SPECIAL EDITION 4Ch 100w midi,rev	886922
E640	INVADER 150 4CH 150W	630000
E642	INVADER 100 4CH 100W	605000
E 610	SAVAGE 120 4C,h 120w, midi,	541078
E645	POWERBALL 100W 4CH	420000
E 625	FIREBALL 60W	295641
ARTIST EDITION SERIE		
E 650	<i>Rithcie Blackmore</i> Signature 4 Ch,100W	354211
CLASSIC LINE		
E 835C	CLASSIC HEAD 50W 4ch	312375
E 350C	CLASSIC COMBO 50W	351422
E 210	CLASSIC CABINET 2*10	125508
E 410C	CLASSIC CABINET 4*10	178500
SOVEREIGN		
E 365	SOVEREIGN 100 COMBO 1*12 V30 4 Ch,100w, rev, midi,	556250
E368	SOVEREIGN 100 COMBO 2*12 V30 4 Ch,100w, rev, midi,	616250
SCREAMER		
E 335	SCREAMER 50 HEAD 50w 4ch rev,	276117
E 330	SCREAMER 50W COMBO 1*12 V30,4 Ch,50W,rev	295641
THUNDER		
E 325	THUNDER 50 HEAD 50W, 3 Ch,rev	211969
E 320	THUNDER 50 COMBO 3 Ch, 1*12 V80,50W, rev.	245438
E 322	SCOTT MOFATT THUNDER COMBO NO REV!	228703
RACKS		
E 530	TUBE PREAMP 4Ch. 1HE, 3Band EQ, St.Line Out.	150609
E 570	Special Edition Preamp	401625
E580	MIDI TUBE PREAMP	669375
E 840/50	POWER AMP 2*50W vol,presence, in gain sw.	291736
E930/60	POWER AMP 2*60W vol,presence, in gain sw.	376523
E950/100	POWER AMP 2X100W	714000
CABINETS		
E412XXL	XXL Cabinet	315000
E 412 VS	PRO CABINET 4*12 VINTAGE 30 SLANTED 240W MONO,	273328
E 412 VG	PRO CABINET 4*12 VINTAGE 30 STRAIGHT 240W MONO	273328
E 412 SS	STANDARD CABINET 4*12 V60 SLANTED 240WMONO	184078
E 412 SG	STANDARD CABINET 4*12 V60 STRAIGHT 240WMONO	184078
COMPACT CABINETS		
E 212 S	CABINET 2*12 120W V60	150609

E412VH	Pro Cabinet 2x12 Vinatage Horizontal	165000
E 212 V	CABINET 2*12 VINTAGE30	161766
E 112 S	CABINET 1*12 V80 60W	104869
E 112 V	CABINET 1*12 V30 60W	108773

ACESSORIES

Z 3	FOOTSWITCH STANDARD	8925
Z 4	FOOTSWITCH METAL/LED	22313
Z 5	FOOTSWITCH / E650,E330,E 335./	46298
Z7	MIDI INTERFACE E 660, E 610, E 365, E 360,E 362,E 930 /	59686
Z 8	RACKMOUNT F Z 7/ Z 11	13945
Z9	Midi Footswitch	53550
Z 10	FOOTSWITCH /E 660,E 610, E 630, E 360, E 362,/	46298
Z 11	MIDI SWITCHER	59686
Z 12	MIDI FOOT CONTROLLER	53550
Z15	MIDI FOOT CONTROLLER	82688